



NOTE:
UNLESS OTHERWISE INDICATED,
ALL RESISTANCE VALUES ARE IN
OHMS, CAPACITANCE VALUES ARE
IN MICROMICROFARADS AND IN-
DUCTANCE VALUES ARE IN
MICROHENRIES.

*T-101 wind number as correct as for 662 0127 ma.
Terminate on 662 0015 as correct marked with second 10, Ant
Start hook up. Serial on primary and DC output cells on
Secondary.*

NOTE: FOR 115 VAC OPERATION CONNECT
JUMPERS AT T8103, AND T104.
RECONNECT T101, CHANGE HR 101
FOR 115 VOLTS OPERATION.

